

XEED SYSTEM UPDATES

Date Issued: January 7, 2022

DOWNLOADING THE HEX FILES

The Xeed System can be updated through a USB drive or an iPad. If the system is being upgraded from SeedView 1.1.3, the upgrade process must be done with a USB drive. If upgrading the system from SeedView 1.1.4 or greater, the system can be upgraded with an iPad. Simply delete the current SeedView app on the iPad, then go to the Apple App Store and search for SM-SeedView. Download and install the new app. When first connected to the Xeed system, the iPad will walk through the appropriate steps to upgrade the system.

1. Go to www.seedmaster.ca.
2. Go to the "Support" tab then click on "Software Downloads".
3. Under the "Xeed / SeedView System" heading, click on the latest software package.
4. The software will begin to download to your "Downloads" folder in File Explorer.
5. After the software has downloaded, navigate to the "Downloads" folder in File Explorer.
6. Right-click on the Software Package then click "Extract All".
7. Verify the folder it is extracting to and click "Extract".
8. Insert a USB drive.
9. Open the Unzipped folder, highlight all five .hex files, right-click and copy them.
10. On the root directory of the USB drive, right-click and paste the .hex files.
11. Once the hex files are copied to the USB, safely remove the USB drive.

INSTALLING THE SOFTWARE

1. Ensure the app is closed on your iPad if applicable.
2. Unplug the CANBUS connection on the XEEDGATE.
3. Insert the USB into the back of the XEEDGATE.
4. Plug the CANUS connection in again.
5. The update will start. The CANBUS light will flash blue.
6. Wait until the CANBUS light is solid green, and the Bluetooth signal LEDs are blinking.
7. Unplug the CANBUS connection.
8. Unplug the USB stick from the back of the XEEDGATE.
9. Plug CANBUS connection in again.
10. Once the update is complete, the app shouldn't be warning you about new versions. If it is, delete the app and reinstall it.

SOFTWARE DETAILS			
HARDWARE PART#	DESCRIPTION	SOFTWARE VERSION	NOTES
iPad	SEED VIEW	1.6.1.1	
270505	XEED GATE	XG_0205	
270505	XEED GATE ISO	XGA_0259	
270515	BASE MODULE	BSM_0151	
270502	XLINER MODULE	XLM_0195	
270500-1 / 270501-1	BLACK EYE SENSOR	BE_0138	